

Adenosine diphosphate (ADP) Assay Kit (Fluorometric)

LS-K202-100 (100 Tests) • Store at -20°C



Introduction

Adenosine diphosphate (ADP) is the product of ATP dephosphorylation by ATPases. ADP can be converted back to ATP by ATP synthases. ADP levels regulate several enzymes involved in intermediary metabolism. Conventionally, ADP levels are measured by luciferase/luciferin mediated assays after ADP is converted to ATP. However, since these assays require measurement of ATP in the sample before conversion of ADP to ATP, if the nascent ATP concentration is significantly higher than the ADP concentration, the ATP signal will drown out the ADP signal. LSBio's newly designed ADP Assay Kit provides a convenient fluorometric means to measure ADP level even in the presence of ATP. In the assay, ADP is converted to ATP and pyruvate. The generated pyruvate is then quantified by a fluorometric method ($\lambda_{ex/em} = 530/590\text{nm}$). The assay is simple, sensitive, stable, high-throughput adaptable and can detect as low as 0.1 M ADP in biological samples.

Key Features

- Safe. Non-radioactive assay.
- Sensitive and accurate. As low as 0.1 μM ADP can be quantified.
- Homogeneous and convenient. "Mix-incubate-measure" type assay. No wash and reagent transfer steps are involved.
- Robust and amenable to HTS: Can be readily automated on HTS liquid handling systems for processing thousands of samples per day.

Applications

- ADP determination in cells and other biological samples.

Components

Component	K202-100
	100 Tests
Reagent A	6 mL
Reagent B	6 mL
Enzyme	120 μL
Standard	100 μL
10% TCA	6 mL
Neutralizer	1.5 mL

Materials Not Supplied

Pipetting devices and accessories (e.g. multi-channel pipette), black flat-bottom 96-well plates (e.g. VWR cat# 82050-676), centrifuge tubes and plate reader.

Storage

The kit is shipped on ice. Store all kit components at -20 °C.

FOR RESEARCH USE ONLY! Not for use in humans.

LifeSpan BioSciences, Inc. • 2401 Fourth Avenue, Suite 900, Seattle, WA 98121
www.LSBio.com • (206) 464-1554 • TechnicalSupport@LSBio.com

Adenosine diphosphate (ADP) Assay Kit (Fluorometric)

LS-K202-100 (100 Tests) • Store at -20°C



Assay Procedure

Use black flat-bottom plates. Prior to assay, bring all reagents to room temperature.

Interference: thiols (b-mercaptoethanol, dithioerythritol etc) at > 10 μM interfere with this assay and should be avoided.

- Standards. Prepare 900 μL 20 μM ADP Premix by mixing 6 μL 3 mM Standard and 894 μL distilled water. Dilute standard as follows.

No	Premix + H ₂ O	ADP (μM)
1	50 μL + 0 μL	20
2	30 μL + 20 μL	12
3	15 μL + 35 μL	6
4	0 μL + 50 μL	0

Transfer 40 μL standards into separate wells of the plate.

- Sample Preparation. Samples high in protein and especially those with likely ATPase activity (cell lysate, serum, etc.) need to be deproteinated and neutralized prior to assaying. To deproteinate, add 25 μL 10% TCA per 100 μL sample. Vortex and centrifuge for 10 min at 14000rpm. Transfer 100 μL of clear supernatant to a clean tube and neutralize with 12.5 μL Neutralizer. For cell assays, at least 1×10⁵ cells should be used. Cells should be lysed and deproteinated at the same time by homogenization in 100 μL dH₂O plus 25 μL 10% TCA per 2×10⁵ cells followed by the centrifugation and neutralization procedure outlined above. Note: Measured ΔRFU's for deproteinated samples need to be multiplied by 1.41 to compensate for the resulting dilution of the sample.
- Transfer 40 μL of each sample to separate wells of a 96 well plate. For samples containing pyruvate, add 40 μL of each sample to 2 separate wells where one well will serve as the sample blank.
- Prepare Working Reagent for each well by mixing 45 μL Reagent A, 45 μL Reagent B and 1 μL Enzyme. If the samples contain pyruvate, sample blanks need to be included. For sample blanks, make the following Working Reagent: 45 μL Reagent A + 45 μL Reagent B (No Enzyme). Add 80 μL of the appropriate Working Reagent to each assay well. Tap plate to mix. Incubate at room temperature for 30 min protected from light.
- Read fluorescence intensity at $\lambda_{exc} = 530$ nm and $\lambda_{em} = 590$ nm.

Calculations

Plot the RFU measured at 30 min for each standard against the standard concentrations. Determine the slope using linear regression fitting. The ADP concentration of a Sample is calculated as

$$[\text{ADP}] = \frac{\text{RFU}_{\text{SAMPLE}} - \text{RFU}_{\text{BLANK}}}{\text{Slope}} \times n \quad (\mu\text{M})$$

where RFU_{SAMPLE} and RFU_{BLANK} are the measured fluorescence values of the sample and sample blank (or H₂O (std #4) if sample blank not *required*) respectively. Slope is the slope of the standard curve in μM⁻¹. *n* is the sample dilution factor (1.41 for deproteinated samples). Note: if the Sample ADP concentration is higher than the 20 μM, dilute sample in water and repeat the assay. Multiply result by the dilution factor.

FOR RESEARCH USE ONLY! Not for use in humans.

LifeSpan BioSciences, Inc. • 2401 Fourth Avenue, Suite 900, Seattle, WA 98121


www.LSBio.com • (206) 464-1554 • TechnicalSupport@LSBio.com

Adenosine diphosphate (ADP) Assay Kit (Fluorometric)

LS-K202-100 (100 Tests) • Store at -20°C



Sample Data



ADP Standard Curve in Water

Version: V.08.09.2018

FOR RESEARCH USE ONLY! Not for use in humans.

LifeSpan BioSciences, Inc. • 2401 Fourth Avenue, Suite 900, Seattle, WA 98121
www.LSBio.com • (206) 464-1554 • TechnicalSupport@LSBio.com